



**Step 1**

First loosen the face panel around your OEM head unit with a PRT (Panel Removal Tool) as shown on the left image.



Pull out but do not fully remove the panel as there are two plastic pins securing it in place as shown on right image.

**Step 2**

On either side of the console, there are two plastic pins which need to be pulled upwards to remove the face panel (see locking mechanism, right).



**NOTE:** A hooking rod and pliers are recommended for this step in order to pull up the top of each pin to release

**Step 3**



Next, undo all of the screws surrounding the OEM head unit.

**Step 4**

Once the screws have been removed, pull off the button panel and disconnect the plug attaching it to the car



**Step 5**

You can now easily remove the head unit, bracket and face assembly. Disconnect all wiring from the back head unit.

