

70-8902**Subaru Outback 2012-up/Legacy with
Harmon Kardon without NAV 2012-up****APPLICATIONS****SUBARU**

Outback	2012-up
Legacy (w/o NAV)	2012-up

Connections to be made**From the 10-pin:**

- Connect the Red wire to the ignition/accessory wire of the aftermarket radio
- Connect the Yellow wire to the radio's 12 volt battery or memory wire.
- Connect the Black wire to the radio's ground wire.
- Connect the Orange/White wire to the illumination wire of the aftermarket radio. If the aftermarket radio does not have an illumination wire, tape off the Orange/White wire.
- Connect the White RCA to the left front RCA output of the aftermarket radio
- Connect the Gray RCA to the right front RCA output of the aftermarket radio

From the 6-pin:

- Connect the Blue wire to the antenna turn on wire of the aftermarket radio.
- Connect the Green RCA to the radio's left rear RCA output.
- Connect the Purple RCA to the radio's right rear RCA output.

From the 28-pin:

- Connect the Blue/White wire to the radio's amp turn on wire if populated on the factory side
- Connect the Green/Purple wire to the reverse wire of the aftermarket navigation radio.
- Connect the Black wire to the radio's ground wire.

The 12-pin harness is a Plug-n-Play connector for the ASWC-1. Please refer to the provided instructions for the ASWC-1 or go to www.axxessinterfaces.com to download the vehicle specific instructions.

