

1999-06 VOLVO S80

DASH DISASSEMBLY

1. Remove Ashtray and shift lever trim.
2. Carefully remove the shifter trim bezel.
4. Remove (2) T-25 Torx Head Screws from the bottom of the climate control panel, remove.
4. Remove (2) T-25 Torx Head Screws from the bottom of the factory radio, remove.

DIN MOUNT INSTALLATION INSTRUCTIONS

Requires new radio's metal sleeve

1. Remove factory radio brackets, reinstall onto the VVOK1056.
2. Insert DIN metal-sleeve from your new radio into the radio opening of the installation kit.
3. Depress the tabs from inside the sleeves opening upward, outward, and downward to secure sleeve to the installation kit.
4. Slide new radio through DIN metal-Sleeve until it locks in place

For information about other American International automotive accessories visit our website at:

<http://www.americaninternational.net>



American International

Automotive Products Division

1040 Avenida Acaso • Camarillo, CA 93012, U.S.A.

USA Sales (800) 336-6500

Canada Sales (888) 922-3006 • USA Fax (805) 388-7950

CUSTOMER HELP LINE

8am-4:30 P.S.T. Monday-Friday Except Holidays

USA 800-323-4329 • Canada 800-245-8777

iVVOK1056



American International
Car Stereo Installation Kits & Accessories



VVOK1056 Mounting Kit

VEHICLE APPLICATIONS

VOLVO

1996-06 S80