

HONK842GB Mounting Kit



www.aampglobal.com **www.aius.net**
2500 East Francis Street Ontario, CA 91761, U.S.A.
Sales: (800) 477-2267
Intl: (727) 572-9255
Support: 888-228-5560

VEHICLE APPLICATION

Honda
2016 CIVIC LX

DASH DISASSEMBLY INSTRUCTIONS

1. Using a soft tool Unsnap and remove both the passenger and driver side trim panels from the side of the shifter and up to the radio along the center console.
2. Gently unsnap and remove the climate controls.
3. From the area now exposed, remove the pop in harness grommet holding the OEM harness
4. Remove (2) Phillips head screws securing the radio mounting brackets
5. Remove factory radio and disconnect all wire harnesses.
6. From the rear of the factory radio remove (4) small Phillips head screws securing the radio dash trim and remove, save for the reinstallation to the HONK842.
7. Remove (4) plastic post clips for use on the HONK842 mainframe.


KIT ASSEMBLY INSTRUCTIONS

Single ISO Mount Application

1. Using the (4) Phillips screws removed during the radio disassembly. Reinstall the OEM radio dash trim to the HONK842 mainframe.
2. Insert pocket into lower section of the brackets and snap into rear pocket support tabs.
3. Install brackets to rear of main frame using the (6) screws provided.
4. Insert ISO mountable radio between ISO mount brackets and loosely attach to sides of radio using screws provided with radio when possible, or screws supplied with kit.
5. Using the main frame of the as a guide, slide radio forward or backward for desired look and then tighten screws to the radio.
6. Reinstall the (4) post clips removed from the factory radio onto the HONK842 mainframe.

Note: Attach a rear support bracket to the rear of the new radio and adjust as necessary to support the weight of the radio. Suggested

Figure A



DOUBLE DIN INSTALLATION INSTRUCTIONS

Double DIN ISO Mount Application

1. Using the (4) Phillips screws removed during the radio disassembly. Reinstall the OEM radio dash trim to the HONK842 mainframe.
2. See Fig B for removal of rear pocket support tabs.
3. Install brackets to rear of main frame using the (6) screws provided.
4. Insert ISO mountable radio between ISO mount brackets and loosely attach to sides of radio using screws provided with radio when possible, or screws supplied with kit.
5. Using the main frame of the as a guide, slide radio forward or backward for desired look and then tighten screws to the radio.
6. Reinstall the (4) post clips removed from the factory radio onto the HONK842 mainframe.

Note: Attach a rear support bracket to the rear of the new radio and adjust as necessary to support the weight of the radio. Suggested.

Figure B

