


KIT ASSEMBLY INSTRUCTIONS


Double DIN

1. Attach the 2 Support Brackets (part# SMB835 L&R) to the rear of the Main Frame of the HONK835 kit using the (6) tiny phillips screws supplied with kit. See Fig. C page 2.
2. Re-attach the (2) panel fastener clips to the left and right Support Brackets (part# SMB835 L&R) of the HONK835 kit. See Fig. C page 2.
3. Attach the left and right side brackets to the main frame. See figure C below.
4. Cut and remove center rib from mainframe and file edges smooth.
5. Follow steps 4-7 from single ISO instructions on page 3. (See note #2 below)
6. Attach a rear support bracket to the rear of the radio components and adjust as needed to allow rear support bracket to rest in the sub-dash (Optional).

NOTE: 1) ISO trim ring (DITR835) must be used in place of after-market radio's trim rings. For ISO mount applications, mount after-market radio components to side brackets using screws provided with radio when possible or hardware included with kit.
2) Spacers must read upright (This side up for DBL ISO install).



**American
International**
Car Stereo Installation Kits & Accessories



HONK835 Mounting Kit

VEHICLE APPLICATIONS

Honda
2005-10 ODYSSEY

CUSTOMER HELP LINE
USA 800-323-4329 • Canada 800-245-8777

DASH DISASSEMBLY AND RADIO REMOVAL INSTRUCTIONS

1. Engage the parking brake.
2. Starting from the left of the shifter, carefully pry the Climate Control/Shifter trim bezel outward.
3. Disconnect all harnesses attached to the rear of the Shifter trim bezel and remove trim bezel.
4. Remove the (3) screws securing the radio to the sub-dash.
5. Carefully pull radio forward, disconnect all harnesses and antenna lead from rear of radio and remove radio.
6. Remove the (2) plastic panel fastener clips from the rear of the factory radio and save.

KIT ASSEMBLY INSTRUCTIONS

Single DIN Mount Applications

1. Attach the 2 Support Brackets (part# SMB835 L&R) to the rear of the Main Frame of the HONK835 kit using the (6) tiny phillips screws supplied with kit. See Fig. C below.
2. Re-attach the (2) panel fastener clips to the left and right Support Brackets (part# SMB835 L&R) of the HONK835 kit. See Fig. C below.
3. Attach the left and right side brackets to the main bracket. See Figure B opposite page.
4. Insert pocket (part # POC835) into lower section of the main frame.
5. Attach left and right side brackets to the rear of the pocket using screws supplied.
6. Insert DIN sleeve from your new radio into the upper section of the installation kit.
7. Depress the tabs from inside the sleeves opening upward, outward, and downward to secure sleeve to the installation kit.
8. Install radio into sleeve and lock into place.
9. Attach a rear support bracket to the rear of the new radio and adjust as necessary to attach to the rear support stud located on the back of the pocket using the small phillips screw supplied with kit (Optional).

Attach Panel Fastener Clip Here





Fig. C



NOTE: ISO trim ring (ITR835) may be used in place of after-market radio's removable trim ring.

KIT ASSEMBLY INSTRUCTIONS

Single ISO Mount Applications

1. Attach the 2 Support Brackets (part# SMB835 L&R) to the rear of the Main Frame of the HONK835 kit using the (6) tiny phillips screws supplied with kit. See Fig. C page 2.
2. Re-attach the (2) panel fastener clips to the left and right Support Brackets (part# SMB835 L&R) of the HONK835 kit. See Fig. C page 2.
3. Attach the left and right side brackets to the main bracket. See Figure B.
4. Insert pocket (part # POC835) into lower section of the main frame.
5. Attach left and right side brackets to the rear of the pocket using screws supplied.
6. Attach (1) ISO Spacer to the inside of upper section on both Left & Right mounting brackets as shown in Fig. A. (See note #2 below)
7. Insert ISO mountable radio between ISO mount brackets and loosely attach to sides of radio using screws provided with radio when possible or hardware included with kit.
8. Slide radio component forward or backward for desired look and tighten screws.
9. Attach a rear support bracket to the rear of the new radio and adjust as necessary to attach to the rear support stud located on the back of the pocket using the small phillips screw supplied with kit (Optional).

NOTE: 1) ISO trim ring (ITR835) may be used in place of after-market radio's removable trim ring.
2) Spacers must read upright (This side up for single ISO install).

